

# Johnsonite®

## Resilient Mouldings

### Maintenance Instructions

---

1. Do not perform any maintenance on the product for 24 hours after installation is completed.
2. Thoroughly sweep or vacuum the entire surface area to remove all loose dirt and grit.
3. Prepare a cleaning solution by mixing 1 to 4 oz. of a neutral detergent (pH of 7-8) per gallon of warm water. The dilution selected depends on light to heavy soil conditions.
4. Scrub the resilient moulding surface with the solution using a clean cloth or sponge.

**Note:** For extremely heavy soil conditions, use Clorox's "Soft Scrub" or equivalent and scrub surface with a damp cloth or sponge.

**Caution:** Do not use abrasive cleaners on Lexan Corner Bumper Guards.

5. Rinse with clean cold water and allow the product to thoroughly dry.
6. If desired, one or two coats of a liquid, acrylic floor finish may be applied to improve gloss level and ease cleaning. Follow manufacturer's directions for application and drying times.

**Caution:** Do not apply floor finish to Lexan Corner Bumper Guards.

7. If questions arise that have not been addressed in the brochure, contact your local Johnsonite distributor for assistance or Johnsonite Customer Service at 1-800-899-8916.

# Johnsonite®

Technical Services Department  
16910 Munn Road, Chagrin Falls, Ohio 44023  
(800) 899-8916 ext 297 Fax (440) 543-8920

www.Johnsonite.com  
E-mail: info @ Johnsonite.com

© 2006 Johnsonite, Inc. A Tarkett Company.