

Installation Instructions



THE ULTIMATE FLOORING EXPERIENCE

Acczent® Wood, Acczent® Steel and Stella

Handling and Storage

- Johnsonite flooring and adhesives must be site conditioned at room temperature for 48 hours prior to, during, and after installation. Room temperature must be maintained between 65° and 85°F (18° and 30°C) with HVAC system operating. A minimum temperature of 55°F (13°C) must be maintained afterwards. The ambient relative humidity should be between 40% and 60%.
- 2. In areas that are exposed to intense or direct sunlight, the product must be

General Subfloor Preparation

 All subfloors must be clean, smooth, flat and dry. The surface must be free of all dust, loose particles, solvents, paint, grease, oil, wax, alkali, sealing/curing compounds, old adhesive, and any other foreign material, which could affect installation. Caution: Do not use oil based sweeping compounds. Fill all depressions, cracks, and other surface irregularities with a good quality Portland cement based underlayment patching compound.

NOTE: Contamination on the substrate can cause damage to the resilient flooring material. Permanent and nonpermanent markers, pens, crayons, paint, etc., must not be used to write on the back of the flooring material or used to mark the substrate as they could bleed through and stain the flooring material. If these contaminants are present on the substrate they must be mechanically removed prior to the installation of the flooring material.

Caution: Do not use liquid solvents or adhesive removers.

Johnsonite does not recommend installing over existing resilient floors. All existing flooring and adhesives must be removed prior to installing the new flooring material. Remove existing adhesive mechanically – do not use chemical adhesive removers or solvents.

Caution: Some resilient flooring products and adhesives contain "asbestos fibers" and special handling of this material is required.

2. Concrete subfloors must be constructed as recommended by the American Concrete Institute's ACI 302.2 "Guide for Concrete Slabs that Receive Moisture-Sensitive Flooring Materials" and prepared to receive resilient flooring protected during the conditioning, installation, and adhesive curing periods, by covering the light source.

3. The highest quality of materials and workmanship is employed in the manufacture of Johnsonite Flooring and careful inspection is made before shipment. However, a quality installation is the responsibility of the installer. It is the installer's responsibility to verify the accuracy of the order and to ensure the materials are checked for damage,

defects, and satisfactory color match. An authorized Johnsonite distributor or Johnsonite representative must be notified of any defects before installation proceeds.

4. Johnsonite cannot accept responsibility for any loss or damage that may result from the use of this information, due to processing or working conditions and/or workmanship outside our control. Users are advised to confirm the suitability of this product by their own tests.

according to ASTM F 710 "Standard Practice for Preparing Concrete Floors to Receive Resilient Flooring".

Do not install Johnsonite flooring over expansion joints.

All concrete subfloors must be tested for moisture, pH (alkalinity), and proper adhesive bond:

Moisture tests shall be conducted in accordance with ASTM F 1869 "Standard Test Method for Measuring Moisture Vapor Emission Rate of Concrete Subfloor Using Anhydrous Calcium Chloride" or ASTM F 2170 "Standard Test Method for Determining Relative Humidity in Concrete Floor Slabs using *in situ* Probes". Three tests should be conducted for areas up to 1,000 sq. ft. and one additional test should be conducted for each additional 1,000 sq. ft. of flooring.

- Results must not exceed 5 lbs. per 1,000 sq. ft. in 24 hours when tested to ASTM F 1869, or exceed 80% when tested to ASTM F 2170.
- If the tests results exceed the limitations, the installation must not proceed until the problem has been corrected.

A pH test for alkalinity must be conducted. Results should range between 7 and 9. If the test results are not within the acceptable range of 7 to 9, the installation must not proceed until the problem has been corrected.

An adhesive bond test should be performed using the actual flooring materials and adhesive to be installed. The test areas should be a minimum of 36" x 36" and remain in place for at least 72 hours and then evaluated for bond strength to the concrete.

3. Wood subfloors must have a minimum 18" (47 cm) of cross-ventilated space between the bottom of the joist and ground. Exposed earth crawl spaces should be sealed with a polyethylene moisture barrier.

Subfloors should meet local and national building codes. Trade associations, such as the APA -"The Engineered Wood Association", offer structural guidelines for meeting various code requirements.

Single Wood and Tongue and Groove subfloors should be covered with 1/4" (6.4 mm) or 1/2" (13 mm) APA approved underlayment plywood. Use 1/4" (6.4 mm) thick underlayment panels for boards with a face width of 3" (76 mm) or less. For boards wider than 3" (76 mm) face width use 1/2" (13 mm) underlayment panels.

Countersink nail heads and fill depressions, joints, cracks, gouges, and chipped edges with a good quality Portland cement based patching compound.

Do not install over OSB (Oriented Strand Board), particle board, chipboard, lauan or composite type underlayments.

- 4. Terrazzo and Ceramic floor surface must be thoroughly sanded to remove all glaze and waxes. Remove or replace all loose tiles and clean the grout lines. Use a Portland cement based leveling compound to fill all grout lines and other depressions.
- **5. Steel floor** surface must be mechanically abraded to assist with the adhesive bond. The floor must be cleaned to remove all dirt, rust and other contaminants. When applying adhesive the non-porous installation instructions must be followed.
- **6.** Concrete floors equipped with a radiant heating system: Turn the heat down to 65°F (18°C) for at least 48 hours before installation. Heat may be gradually returned to operating temperature 48 hours after installation. Temperature should not exceed 85°F (30°).

Heterogeneous Sheet Installation

- 1. Recommended Adhesives:
 - **a.** For standard application use: Johnsonite 925 Resilient Flooring Adhesive Trowel: porous substrate: 1/16" x 1/16" x 1/16" 'V' notch Trowel: non-porous substrate: 1/32" x 1/16" x 1/32" 'U' notch

Caution: The 925 adhesive is sensitive to substrate porosity. Determine substrate porosity and adhesive follow the label instructions regarding porous and non-porous substrate drying times prior to the installation.

b. For application in areas subject to heavy point loads, rolling loads, topical moisture, or temperature extremes use:

Johnsonite 975 Two-Part Urethane Adhesive

Trowel: porous and non-porous substrates: 1/32" x 1/16" x 1/32" 'U' notch

Caution: When installing with 975 Two-Part Urethane Adhesive the installer must work off of the flooring material or use kneeling boards to prevent adhesive during displacement the installation and rolling process.

c. SpraySmart Adhesive System: Johnsonite 130 Resilient Flooring Spray Adhesive: Approximate coverage: 150 - 185 sq.

ft. per 22oz. can

Caution: The **SpraySmart** Adhesive System is unique; instructions on can must be followed.

Note: Contact Johnsonite Technical Department prior to use for training.

2. Adhesive Application: Follow adhesive label instructions for proper use.

3. Sheet Installation:

- a. Install rolls in sequential order following roll numbers on the labels.
- **b.** Reverse sheets on non-pattern material
- c. Do not reverse sheets on patterned (wood grain) material.
- **d.** Cut pieces to length allowing approximately 3" (76 mm) excess for trimmina.
- e. Cut the first piece to fit by freehand knife, direct scribing or pattern scribing method.

i. Seams – Double-Cut Method:

- **1.** Position remaining sheets so that the top sheet overlaps the previous sheet by 1" (25 mm).
- installing 2. When patterned material, pattern should be properly aligned before cutting the seam.
- 3. Insert a scrap piece of material

under the seam before double cutting.

- 4. Double cut through both sheets using a sharp knife. Cut should be perpendicular, do not angle blade
- ii. Seams (Wood -Patterned Grain | Material – Recess Scribe Method:
 - 1. Remove the factory seam edge of the first piece of material using a straight edge and knife to trim seam by following the pattern of the material
 - 2. Position all remaining sheets so that the top sheet overlaps the previous sheet, pattern should be properly aligned before cutting seam. Trim off opposite seam edge; follow the pattern of the material, using a straight edge and knife.
 - 3. Following the edge of the first piece, under scribe the seam.
 - 4. Insert a scrap piece of material under the scribe mark to protect the seam edge of the first piece.
 - 5. Use a sharp knife to cut the seam following the scribe mark. Cut should be perpendicular, do not angle the knife blade.

iii. Seams -Non-Patterned Material - Recess Scribe Method:

- 1. Remove 1/2" (13 mm) off the factory seam edge of the first piece of material using an edge trimmer or straight edge and knife
- 2. Position all remaining sheets so that the top sheet overlaps the previous sheet by 1/2" (13 mm). Trim 1/2" (13 mm) off opposite seam edge using an edge trimmer or straight edge and knife.
- 3. Following the edge of the first piece, under scribe the seam.
- 4. Insert a scrap piece of material under the scribe mark to protect the seam edge of the first piece.
- **5.** Use a sharp knife to cut the seam following the scribe mark. Cut should be perpendicular, do not angle the knife blade.
- 6. Fold back the sheets and apply the adhesive to the substrate and allow proper open time following the adhesive label instructions.
- 7. Roll the flooring in both directions using a 100 pound three-section roller. Use a hand roller in areas that cannot be reached with a large roller.
- 8. Vinyl sheet flooring must be welded using the Heat Weld or Cold Weld methods listed below.

4. Seams: All seams must be welded. a. Heat Weld Seam:

- 1. Note: It is recommended to heat weld seams to provide a more sterile and a water tight seam.
- **2.** Recess scribe the seam with a slight gap not to exceed 1/64" (0.4mm) to help guide the router.
- **3.** Insert a scrap piece of material under the scribe mark to protect the seam edge of the first piece.
- 4. Use a sharp knife to cut the seam following the scribe mark. Cut should be perpendicular, do not angle the knife blade.
- 5. Remove the scrap piece of material and seam trimmings before rolling the seam with a small hand roller.
- 6. Roll the seam area with a 100 pound three-section roller.
- 7. Wait a minimum 24 hours after installation before heat welding the seams
- 8. Rout approximately 2/3 of the thickness of the material.
- 9. Use Johnsonite vinyl weld rod. b. Cold Weld Seam:

- 1. Recess scribe or double cut the seam to provide a **net** fit.
- 2. When recess scribing insert a scrap piece of material under the scribe mark to protect the seam edge of the first piece.
- **3.** Use a sharp knife to cut the seam following the scribe mark. Cut should be perpendicular, do not angle the knife blade.
- 4. Remove the scrap piece of material and seam trimmings before rolling the seam with a small hand roller.
- 5. Roll the seam area with a 100 pound three-section roller.
- 6. Wait at least 2 to 3 hours after the flooring material has been installed before applying the Johnsonite Cold Weld Liquid.
- 7. Refer to the Cold Weld instructions for complete Cold Weld Liquid application details.

5. Flash Coving:

- a. Use Johnsonite CFS-00-A Cove Filler Strip.
- b. Apply 925 Resilient Flooring Adhesive to wall area using a trowel or paint brush.
- c. Net fit the flooring material into the cove cap.
- d. Roll the coved material with a small hand roller.

6. Traffic:

- a. No traffic for 24 hours after installation.
- b. No heavy traffic, rolling loads, or furniture placement for 72 hours after installation

Adhesive Clean Up

Excess adhesive should be removed during the installation process. 925 Resilient Flooring Adhesive 975 Two-Part Urethane Adhesive

- 25 Resilient Flooring Adnesive
- Use a clean white cloth dampened with water to remove wet adhesive from floor covering and tools.
- Dried adhesive may require the use of denatured alcohol applied to a clean white cloth. (Follow manufacturer's precautions when using denatured alcohol.)

Before the adhesive sets, remove excess adhesive from flooring and clean tools with denatured alcohol applied to a clean white cloth. (Follow manufacturer's precautions when using denatured alcohol.)

- Do not allow adhesive to dry on the flooring surface.
- Removing dried adhesive may cause irreparable damage to the flooring surface.

Johnsonite SpraySmart System

- Use a clean white cloth dampened with water to remove wet adhesive from floor covering and tools.
- Dried adhesive may require the use of denatured alcohol applied to a clean white cloth. (Follow manufacturer's precautions when using denatured alcohol.)

Maintenance

- **1.** Wait 72 hours after installation before performing initial cleaning.
- **2.** A regular maintenance program must be started after the initial cleaning.
- **3.** Refer to Johnsonite's Maintenance Instructions for complete details.

Check Web Site (www.johnsonite.com) for current instructions. Contact Johnsonite at (800)-899-8916 with any questions.



THE ULTIMATE FLOORING EXPERIENCE

Technical Services Department 16910 Munn Road, Chagrin Falls, Ohio 44023 (800) 899-8916 ext 9297 Fax (440) 632-5643 www.johnsonite.com email: info@johnsonite.com © 2011 Johnsonite Inc.